

**Learning today Leading tomorrow** 

## **Computer Engineering Technology**

## Fall 2019

247-105-VA CIRCUIT ANALYSIS AND SIMULATION

.

## **LABORATORY EXPERIMENT #2**

## **Resistors**

Week 2


Student name: Leonardo Fusser (1946995)

### **Objective**

Identify and predict resistors values by using colour code and practice measuring resistance using Ohmmeter

#### **Resistor Color Code**


Since resistors are small enough that any printing on them would be hard to read, most are marked with 3 to 5 bands of color:



#### Surface mount resistors



#### **Resistors** power



#### Standard EIA Color Code Table 5 Band: ±.1%, ±.25%, ±.5%, ±1% 1st 2nd 3rd 4th 5th Band Band Band Band Band 1st Band 2nd Band 3rd Band 4th Band 5th Band Color (1st figure) (2nd figure) (3rd figure) (multiplier) (tolerance) Black 10<sup>1</sup> Brown ±1% Red 10<sup>2</sup> 3 3 3 10<sup>3</sup> Orange Yellow 4 4 4 104 5 5 5 10<sup>5</sup> Green Blue 6 6 10<sup>6</sup> ±.25% 6 Violet 107 ±.1%

8

9

10<sup>8</sup>

10<sup>9</sup>

10-1

**Question1** What is the color code for the following resistors? \*Assuming all resistors have a +/-1% tolerance.\*

(1)220Ω, (2)100Ω, (3)33Ω, (4)1ΚΩ, (5)4.7ΚΩ, (6)10ΚΩ, (7)100ΚΩ, (8)56ΚΩ, (9)22ΜΩ, (10)820ΚΩ

1(red,red,brown,brown) 2(brown,black,brown,brown) 3(orange,orange,black,brown)

4(brown,black,red,brown) 5(yellow,violet,red,brown) 6(brown,black,orange,brown)

7(brown,black,black,orange,brown) 8(green,blue,orange,brown) 9(red,red,blue,brown)

10(gray,red,black,orange,brown)

Gray

White


Gold

8

8

9

#### **Question2** What is the value of the following resistors?



orange,red,brown,brown,brown=3.21K $\Omega$ 

green,red,brown,black,brown=521Ω

grey,red,orange,gold=82KΩ

orange,orange,brown,N/A=330Ω

**Question3** Take 5 resistors and make a table that contains.

		Colours		Value	+/-	Expected					
						tolerance	range.				
blue	grey	orang.	gold	-	68ΚΩ	5%	64.6ΚΩ-				
			,				71.4KΩ				
red	red	orang.	gold	-	22ΚΩ	5%	19'950Ω-				
							22'050Ω				
green	blue	red	gold	-	5.6ΚΩ	5%	4'750ΚΩ-				
							5'250Ω				
brow.	black	red	gold	-	1ΚΩ	5%	950Ω-				
							1050Ω				
yello.	viole.	orang.	gold	-	47ΚΩ	5%	45'600Ω-				
			)				50'400Ω				

**Question4** Learning how to use the Ohmmeter and how to set it to zero how to read the values.



**Question5** Measure each resistor that you took it and make a table that contains.

		Colors			Value	Measured	%Error
					+/-	Value	
					tolerance		
blue	grey	orang.	gold	-	5%	67ΚΩ	1.5%
red	red	orang.	gold	-	5%	21ΚΩ	4.5%
green	blue	red	gold	-	5%	5ΚΩ	10%
brow.	black	red	gold	-	5%	1ΚΩ	0%
yello.	viole.	orang.	gold	-	5%	48ΚΩ	2%


**Question6** Connect 2 resistors in series and measure the result compare if  $R_{total} = R_1 + R_2$ .

Rtotal=89K $\Omega$ 


 $R_1=67K\Omega$ 

 $R_2=21K\Omega$ 

# **Question7** Take a Breadboard and find out the construction of the Breadboard. Check the wholes that are connected together and show in the following Breadboard.



**Question8** Put 2 resistors in series on breadboard and repeat Question 6.



**Question9** Put 3 resistors in series on breadboard and repeat part 5.

Rtotal=95K $\Omega$ R1=68K $\Omega$ R2=21K $\Omega$ R3=5K $\Omega$